


Travelhop



COMBINATION LOCK INSTRUCTIONS

The factory/default combination is 0-0-0. To set your personal combination please follow the instructions below:

1. Turn the dials to their original combination 0-0-0.
2. Slide the button in the direction of the arrows.
3. Set your combination by turning the dials, for example 8-8-8.
4. Slide the button back in place.

Now your personal combination is set.

Please remember your personal combination by heart.